


WIRING A HORNBY MOTORISED TURNTABLE



Turntable (TT) black wire must be connected to the same rail as the black wire in the track plug